



VERSAMax™

Versa Max Utility Trailer

Spare Tire Carrier Assembly Instructions



TOOLS REQUIRED

1. 9/16" Wrench
2. 13/16" Deep Socket
3. Torque Wrench

Spare Tire Carrier Assembly Instructions



1. Place a tie down cam in the top slot of the trailer in the desired location.
2. Insert the inner groove of the spare tire carrier in the slot at the bottom of the trailer. Press the spare tire carrier flush against the trailer, and align the spare tire carrier so that the hole in the spare tire carrier lines up with the tie down cam.
3. Place a $3/8-16 \times 3/4$ " bolt through the hole in the spare tire carrier and into the tie down cam. Tighten the bolt using a $9/16$ " wrench.

Spare Tire Carrier Assembly Instructions



4. Place the tire onto the two studs of the spare tire carrier, so that one hole of the tire is above the spare tire carrier studs.
5. Place a lug nut on each spare tire carrier stud.
6. Torque each lug nut to 90-120 ft/lbs.

